



CRESTRON HOME® APP QUICK START GUIDE





The features shown are for illustrative purposes only. The actual features shown on your device may vary depending on how the application is configured and the particular devices being controlled. Contact your Crestron dealer for more information.

Welcome to your Crestron smart home.

The Crestron Home App makes it easy to access and control every aspect of your home — from your phone, tablet, or touch screen.

This guide will walk you through basic navigation, room controls and settings, and how to make your Crestron smart home your own. So let's get started.

HOME PAGE - MAIN NAVIGATION

Navigating your Crestron smart home starts here.



Currently selected home. See status of security system, door locks, and climate.

Quick Actions are like shortcuts. They give you the ability to easily execute a **Scene**, or a combination of different commands, with one tap.

Tap ... for more advanced settings.

To choose your home page image, see page 32.


Home Controls apply to systems that affect your entire home. Simply swipe up to see every system available to you..

Home button appears on every page, so you can always quickly navigate your way back.


Rooms button gives you control of all the different rooms and areas in your home.

ROOMS

Manage how you'd like to view your home.




Swipe here to select the room you want.
Rooms are organized by floor or area.



Standard view

- Each room can be given a unique name and custom image.
- Tap ♥ to designate a room or area a Favorite. Favorites will appear at the top.
- Tap ☎ to page the touch screen in this room.
- Tap 🚫 to toggle "do not disturb" mode for each room.
- Key information about each room is displayed here.



Compact view

ROOM VIEW

See every action you can take in each room.

This diagram illustrates the light-themed Room View interface for a 'Living Room'. At the top, a back arrow is on the left, and a menu icon (three dots) is on the right. Below the header, the room name 'Living Room' is displayed above a status bar showing '74° — Cooling to 72°' and 'Lights are on. Living room lock is unlocked.' The interface is divided into two main sections: 'Actions' and 'Services'. The 'Actions' section contains two tiles: 'Room Off' with a red stop icon and 'Winding Down' with a lightbulb icon. The 'Services' section contains two columns of tiles: 'Lights' with an off icon and a lightbulb icon, and 'Shades' with a closed icon and an open icon. At the bottom, there is a 'Spotify in Living room' tile and a 'Climate' tile with a sun icon. Callout lines point to various elements: the back arrow, the menu icon, the room status bar, the 'Actions' section, the 'Services' section, the 'Climate' tile, and the bottom home indicator area.

Tap < to go back to the main **Rooms** page.

Use ... to access more advanced settings.

Your personal room image confirms you're in the room you want to control.

Displays status of systems in the room.

Tap to activate Quick Actions such as on or off.

Tap tiles to access **Room Services** for more advanced controls.

Tap to go back to the main Rooms page.

With Room Services you can finely control everything from lights and shades, to temperature, music, and video.

Dark Mode
Select in your iOS® device settings, as usual.

Press + or - to adjust temperature. Tap the **Climate** tile to access more advanced control.

Music and **Video** tiles display what's currently playing in the room.


This diagram illustrates the dark-themed Room View interface for a 'Living Room'. The layout is similar to the light theme but with a dark background. The 'Actions' section has 'Room Off' with a red stop icon and 'Entertain' with a green star icon. The 'Services' section has 'Lights' with an off icon and a lightbulb icon, and 'Shades' with a closed icon and an open icon. The 'Thermostat' tile shows '72°' with 'COOLING, F.H.: ON (75°F)' and a set point of '69°'. The 'Music' tile shows 'NOT PLAYING' and the 'Living Room Lock' tile shows 'UNLOCKED'. A hand icon is shown interacting with the thermostat controls. Callout lines point to the back arrow, menu icon, room status bar, 'Actions' section, 'Services' section, thermostat controls, music and lock tiles, and the expand/collapse arrow.

Tap **Lights** or **Shades** to access simple actions such as On, Off, Open, or Close.

Tap **Music** and **Video** tiles to access basic controls.

SECURITY


Access and control your alarms, entry locks, and cameras from wherever you happen to be.




Tap to select **alarm system**.

Quickly secure home.

Tap to select **cameras**.




Quickly view and adjust **alarm status**.



Control **door locks**, **garage doors**, and **gates**.

Real-time feedback of lock status.




Tap **preview image** to view live stream. Preview image updates every few seconds.

Mark **Favorites** to have them appear at top of list.

CLIMATE


Set the perfect temperature in every room.
Maximize energy savings.



Check thermostat set points and current temperature in every room. Tap + or - to adjust temperature.




Tap individual thermostat tile for more information and advanced controls.



Tap and move set points dynamically.

Tap + or - to adjust temperature.



Tap **Mode** to access specific climate settings such as Cool or Heat.

CLIMATE

Program your home to adapt to the seasons.

Use **Scheduled Events** to automatically activate season-specific settings.

All scheduled events will show in this window.

Tap arrow to edit and view event details.

Key event details will appear on screen.

Tap to create new **Scheduled Event**.

9:41

Scheduled events

Thermostat 1

11.30 AM, WEEKDAYS
Summer schedule
68° 75° 70°

11.30 AM, WEEKDAYS
Fall transition schedule
66° 72° 70°

11.30 AM, WEEKDAYS
Winter schedule
64° 72° 71°

Create new scheduled event

9:41

New climate scheduled event

NAME
Summer schedule

ACTIVE DAYS
S M T W T F S

START
9 10 11 12 30 35 40 AM PM

SET POINTS
68°F COOL TO
75°F HEAT TO
70°F AUTO

SCHEDULED STATUS
Schedule enabled

Save

Tap to highlight the days event should be active.

Swipe up or down to select start and end time.



Tap to set points temperature.

Tap to schedule event and then press save to activate event.



LIGHTS


Fine-tune room lighting to set the perfect mood for any activity.



LIGHTS

Continued.

Tap **Lights** tile to access whole home lighting control.



Tap arrow to hide tiles for a floor.



Tap to access whole home scenes control.

Tap to turn all lights on or off on a floor.

Tap icons to toggle all lights in a room.


Tap tile to select a scene.

Scroll to access more floors.



SHADES

Manage natural light for different activities;
ensure privacy at night; enhance energy savings.



Tap to activate available
Shades Scenes.

Tap to command all shades
to let in more light or less light.


Charge status for
battery-powered shades.

Tap to control each shade
or shade group.




MUSIC

Play your favorite music throughout your home, or different music in every room.




Tap tiles to access **Now Playing Screens**.


Tap **Music** on your Home page to access the **Now Playing** page. See what's playing in any room.



Tap the room tile for more information on audio in that room.




Tap to open your music in Sonos® app.



Tap to select your favorite artists/music.


Tap to select source. Checkmark will appear to confirm selection.



MUSIC


Continued.

Tap to select rooms in which to play music.




Tap to access multiroom or whole home music control.

Select rooms in which you want to play music.



Create "Groups" of individual rooms.

Adjust volume in each room.




Adjust volume across all rooms.




VIDEO

Enjoy your favorite entertainment in every room.




Choose your entertainment service or source with a single tap.



See what's currently playing in home theater. Tap tile for more information.

Active media shows what's now playing in home theater.



Tap arrow to change source.

Tap to turn video off.

VIDEO

Continued.


Tap the arrow to select source.

Tap to turn off current source.


Controls with Cable TV as selected source.

Swipe to adjust volume.

Access more advanced controls, including Favorites.




Favorites – two views.




Tap to edit TV presets.

Additional command list for TV and projector.



Displays what is currently playing and what's up next on favorite channels.

Route multiple sources with a single tap.




Select source for each TV or projector.

Choose audio source.



POOL & SPA

Make your personal oasis feel like heaven.




Dark Mode is easier on the eyes, especially in dimly lit environments.

See current status and set the scene for your favorite pool activities with one tap.

Set preferred water temperature.

Control all pool/spa features, e.g. waterfall, slide, jet speed, and lights.




HOME SELECTOR

Have more than one residence with a Crestron smart home system?
The Crestron Home app makes it easy to manage and control them, remotely or on-premises.




Tap to view more options, and then select **Manage Home**.




Home page


Tap  to change between standard and compact view.




«  » Swipe left or right to select the Crestron smart home you wish to control.



CHANGE YOUR HOME IMAGE




Step 1
Tap 3 horizontal dots.




Step 2
Tap **Change Image**.


Create an experience that reflects how and where you live.



Step 3
Select image source.




Step 4
Choose photo.



Step 6
Enjoy.

ONE EXPERIENCE

Enjoy the consistent ease of the Crestron Home app across every control device in your home.




Android™ device


iOS® device

ONE EXPERIENCE


Control your environment with our beautifully designed, easy-to-use touch screens.



10-inch



8-inch




5-inch Portrait



Remote

ONE EXPERIENCE

With Crestron, everything in the home is controlled with ease on one intelligent platform. Your home becomes more secure, comfortable, and convenient.



A room that awakens with a single touch. An environment that adjusts to every mood. The peace of mind that comes with knowing your house is safe and sound, no matter where you are. Crestron Home® OS elevates your living experience, transforming everyday commands into instantaneous delight.



The features shown are for illustrative purposes only. The actual features shown on your device may vary depending on how the application is configured and the particular devices being controlled. Contact your Crestron dealer for more information.



World Headquarters 15 Volvo Drive Rockleigh, NJ 07647 800.237.2041 201.767.3400 crestron.com

All brand names, product names, and trademarks are the property of their respective owners. Certain trademarks, registered trademarks, and trade names may be used in this document to refer to either the entities claiming the marks and names or their products. Crestron disclaims any proprietary interest in the marks and names of others. Crestron is not responsible for errors in typography or photography.
©2026 Crestron Electronics, Inc.